


The loop isolator module isolates short circuits from the speaker line to prevent the entire line to fail. In this case it informs the loop monitor VM-300IM about that fault through the speaker line. The isolator module is in a housing with screw connectors outside.



Article number: VM-300IS-EB QJ

Specifications

Power source	supplied from VM-300IM
Input / Output	loop in, loop out, speaker
Indicator	Status: OK / short at loop in / fault at loop out / initialise
Dimensions (W x H x D)	88 x 60 x 34 mm
Dimensions (ø x D)	x 34 mm
Operating temperature	-10 to +55°C



VM-300IS-EB

Appearance