

VOICE EVACUATION FRAME 4AB

VX-3004F

■DESCRIPTION

The VX-3004F is a device designed to control the Voice evacuation announcements of TOA's VX-3000 Series rack-mount type voice evacuation system which is compliant with the European Standard EN54 for fire alarm systems. It has audio input terminals and can output the amplified audio signals to the speaker lines when the optional power amplifier modules are mounted. It is possible to make an Emergency Warning Broadcast assigned a higher priority than the Emergency broadcast.

It is possible to make an Emergency Warning Broadcast assigned a higher priority than the Emergency broadcast. Two patterns of the Emergency broadcast can be activated simultaneously. Compatible with network, the system can be configured in distributed arrangement. Features include the following functions: Digital signal processing function that enables appropriate acoustic adjustment for individual input sound sources and output areas, Feedback suppressor function that automatically suppresses acoustic feedback when it occurs, VOX function that allows start/stop control of broadcast by way of an audio trigger, and ANC function that enables an ambient noise control. (The ANC function distinguishes between the unit's output sound and the ambient noise. The unit's output sound is not detected as noise.) Indicators that show such statuses as fault status and power amplifier signal status are provided. It has 4 speaker output channels, each of which is provided with A and B lines to enable duplication of the speaker lines. Up to 4 power amplifier modules can be mounted. The 4-channel amplifier can be used either for zone output or standby use.

As the VX-3004F is equipped with Standby amplifier input/output terminal, the standby amplifier, when mounted, can be shared among VX-3000F units.

■ SPECIFICATIONS

Power Source	20 - 33 V DC, removable terminal block (4 pins)
Power Consumption	24 W (frame only) at 33 V DC input, 90 W (RS LINK: 2 A output) at 33 V DC input
LAN A, B	Number of Connectors: 2 (LAN A, LAN B)
	Network I/F: 100BASE-TX
	Network Protocol: TCP, UDP, ARP, ICMP, RTP, IGMP, FTP, HTTP
	Spanning tree Protocol: RSTP
	Audio Transmission System: TOA Packet Audio (*1)
	Audio Encoding Method: PCM
	Audio Sampling Frequency: 48 kHz
	Audio Quantifying Bit Number: 16 bits
	Connection Device: VX-3004F, VX-3008F, VX-3016F, NX-300, Switching HUB
	Connector: RJ45 connector
	Connection Cable: Category 5 twisted pair cable (CAT5) or greater
	Number of Stages of Cascade connection: UP to 7
	Maximum Cable Distance: 100 m (328.08 ft)
RS Link A, B	Number of Connectors: 2 (RS LINK A, RS LINK B)
	Audio input level: 0 dB (*2)
	Power feed: Max. 1 A per connector
	Connector: RJ45 connector
	Connection Cable: Shielded Category 5 twisted pair cable (CAT5—STP) or greater
DC 1:1	Maximum Cable Distance: 1200 m (3937.01 ft)
DS Link	Connection Device: DS LINK of Power supply units
Analog Link	Connector: RJ45 connector
	Connection Cable: Shielded Category 5 twisted pair cable (CAT5—STP) or greater
	Maximum Cable Distance: 5 m (16.4 ft)
	Number of Connectors: 1 input, 1 output
	Connection Device: VX-3004F, VX-3008F, VX-3016F
	Connector: RJ45 connector
	Connection Cable: Shielded Category 5 twisted pair cable (CAT5-STP) or greater
Control Innut 1 2	Maximum Cable Distance: 800 m (2624.67 ft) 16 inputs, no-voltage make contact input, open voltage: 24 V DC,
Control Input 1, 2	short-circuit current: 2 mA
	Fault Detection System: Short circuit, Open circuit, Method: Voltage detect
	Connector: RJ45 connector
	Connection Cable: Shielded Category 5 twisted pair cable (CAT5—STP) or greater
Emergency Control IN	Input 2: Isolated voltage input, -24 to +24 V
	Connector: RJ45 connector
	Connection Cable: Category 5 twisted pair cable (CAT5) or greater
VOX Function	Threshold: -60 to 0 dB (1 dB steps)
	Hysteresis: 0 to +10 dB, Hold time: 10 ms - 10 s
	Settable for each audio input
Control Output 1, 2	General outputs: 8 with CONTROL OUTPUT 1
ooner or output 1, 2	Exclusive outputs: 3 with CONTROL OUTPUT 2
	GENERAL FAULT, CPU FAULT, CPU OFF
	No-voltage make contact, electrical contact output,
	control current: 10 mA, withstand voltage: 28 V DC
	Connector: RJ45 connector
	Connection Cable: Shielded Category 5 twisted pair cable (CAT5—STP) or greater



TOA VOICE EVACUATION FRAME 4AB VX-3004F

■ SPECIFICATIONS

■ 3F LUIT TUATION 3	
ATT/Control Output	8 outputs, no-voltage make contact, relay contact (NC, NO, C), control current: 2 mA to 5 A, withstand voltage: 125 V AC, 40 V DC Connector: Removable terminal block (12 pins) ···2
Audio Input 1, 2, 3, 4	4 inputs
Audio Input I, 2, 3, 4	Sensitivity:
	LINE: -20 dB (*2), MIC: -60 dB (*2)
	LINE/MIC/ANC Sensor (changeable with setting software)
	Gain Control: volume adjustable with volume control (internal front panel)
	$-\infty$ to 0 dB
	Input Impedance: 47 k Ω , electronically—balanced
	Frequency Response: 40 Hz - 20 kHz ±1 dB (at DA CONTROL LINK, 0 dB output)
	Distortion: 1% or less (at DA CONTROL LINK, 0 dB output, 1 kHz)
	Signal to Noise Ratio: 60 dB or more (at DA CONTROL LINK, A—weighted)
	Phantom Power Supply: 24 V DC, can be set with setting software
	Connector: Removable terminal block (6 pins)2
Digital Cianal Drassasina	Conflictor. Nemovable terminal block to pins/ "2
Digital Signal Processing	7 filtage (guta)
Feedback Suppression	7 filters (auto),
Function (FBS)	Settable for each audio input and RS LINK (A/B)
Equalizer/Filter	3 bands for each audio input and RS LINK (A/B),
'	6 bands for each amplifier output
	Parametric equalizer: 20 Hz - 20 kHz, ±15 dB, Q: 0.267 - 69.249
	Filtering: High-pass filter 20 Hz - 20 kHz, 6 dB/oct, 12 dB/oct
	Filtering: High-pass filter 20 Hz - 20 kHz, 6 dB/oct, 12 dB/oct Low-pass filter 20 Hz - 20 kHz, 6 dB/oct, 12 dB/oct
	High shelving filter 6 - 20 kHz, ±15 dB
	Low shelving filter 20 - 500 Hz, ±15 dB
	Notch filter (amplifier output only) 20 Hz - 20 kHz, Q: 8.651 - 69.249
	All-pass filter (amplifier output only) 20 Hz - 20 kHz, Q: 0.267 - 69.249
Compressor	Horn equalizer (amplifier output only) 20 kHz, 0 to +18 dB (0.5 dB steps)
	Threshold: -20 to 0 dB (1 dB steps)
	Ratio: 1:1, 1.1:1, 1.2:1, 1.3:1, 1.5:1, 1.7:1, 2:1, 2.3:1, 2.6:1, 3:1, 4:1,
	5:1, 7:1, 8:1, 10:1, 12:1, 20:1, ∞:1
	Attack time: 0.2 ms — 5 s, Release time: 10 ms — 5 s
	Gain: $-\infty$ to +10 dB, Knee type: hard knee, middle knee, soft knee
Delay	For each amplifier output, 0 — 2730 ms (0.021 ms steps)
ANC	Amplifier output level control, Automatic sensor input reference level measuring,
(Ambient Noise Control)	Sensor input reference level fine adjustment
THE STORE THOUSE SOLLET	Maximum output signal level control: -15 to 0 dB
	Minimum output signal level control: -18 to -3 dB
	Sample time setting: 10 s, 20 s, 30 s, 1 min, 5 min
	Gain ratio setting: (Ambient noise: Output signal level) 6:3, 5:3, 4:3, 3:3, 3:4, 3:5, 3:6
	Ambient noise measuring frequency setting: 20 Hz — 20 kHz, 3 points
Canadian Line	Ambient noise measuring frequency setting: 20 Hz — 20 kHz, 3 points
Speaker Line	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal
Speaker Line	Ambient noise measuring frequency setting: 20 Hz — 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms
Speaker Line	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1
Speaker Line	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault,
	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line
	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault,
Standby Amplifier	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1
Standby Amplifier	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1 Maximum Voltage/Current: 100 Vrms, 5 Arms
Standby Amplifier Input/Output	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1 Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (2 pins) ···2
Standby Amplifier Input/Output	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1 Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (2 pins) ···2 Number of Amplifiers: 4
Standby Amplifier Input/Output Power Amplifier	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1 Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (2 pins) ···2 Number of Amplifiers: 4 Connector: DA CONTROL LINK ···4, DA OUTPUT LINK ···4
Standby Amplifier Input/Output Power Amplifier	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1 Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (2 pins) ···2 Number of Amplifiers: 4 Connector: DA CONTROL LINK ···4, DA OUTPUT LINK ···4 POWER (green) ···1, RUN (green) ···1, EMERGENCY (red) ···1, CPU OFF (red) ···1,
Standby Amplifier Input/Output Power Amplifier	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1 Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (2 pins) ···2 Number of Amplifiers: 4 Connector: DA CONTROL LINK ···4, DA OUTPUT LINK ···4 POWER (green) ···1, RUN (green) ···1, EMERGENCY (red) ···1, CPU OFF (red) ···1, LAN A (green) ···1, LAN B (green) ···1, RS LINK A (green) ···1, RS LINK B (green) ···1
Standby Amplifier Input/Output Power Amplifier	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1 Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (2 pins) ···2 Number of Amplifiers: 4 Connector: DA CONTROL LINK ···4, DA OUTPUT LINK ···4 POWER (green) ···1, RUN (green) ···1, EMERGENCY (red) ···1, CPU OFF (red) ···1, LAN A (green) ···1, LAN B (green) ···1, RS LINK A (green) ···1, RS LINK B (green) ···1 FAULT STATUS (yellow)
Standby Amplifier Input/Output Power Amplifier	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1 Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (2 pins) ···2 Number of Amplifiers: 4 Connector: DA CONTROL LINK ···4, DA OUTPUT LINK ···4 POWER (green) ···1, RUN (green) ···1, EMERGENCY (red) ···1, CPU OFF (red) ···1, LAN A (green) ···1, LAN B (green) ···1, RS LINK A (green) ···1, RS LINK B (green) ···1 FAULT STATUS (yellow) GENERAL ···1, UNIT ···1, NETWORK ···1, EMG MIC ···1, FUSE ···1, POWER ···1, CPU ···1,
Speaker Line Standby Amplifier Input/Output Power Amplifier Indicators	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault,
Standby Amplifier Input/Output Power Amplifier	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1 Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (2 pins) ···2 Number of Amplifiers: 4 Connector: DA CONTROL LINK ···4, DA OUTPUT LINK ···4 POWER (green) ···1, RUN (green) ···1, EMERGENCY (red) ···1, CPU OFF (red) ···1, LAN A (green) ···1, LAN B (green) ···1, RS LINK A (green) ···1, RS LINK B (green) ···1 FAULT STATUS (yellow) GENERAL ···1, UNIT ···1, NETWORK ···1, EMG MIC ···1, FUSE ···1, POWER ···1, CPU ···1,
Standby Amplifier Input/Output Power Amplifier	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault,
Standby Amplifier Input/Output Power Amplifier Indicators	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault,
Standby Amplifier Input/Output Power Amplifier	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault,
Standby Amplifier Input/Output Power Amplifier Indicators	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault, Method: Impedance or End of line Input: 1, Output: 1 Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (2 pins) ···2 Number of Amplifiers: 4 Connector: DA CONTROL LINK ···4, DA OUTPUT LINK ···4 POWER (green) ···1, RUN (green) ···1, EMERGENCY (red) ···1, CPU OFF (red) ···1, LAN A (green) ···1, LAN B (green) ···1, RS LINK A (green) ···1, RS LINK B (green) ···1 FAULT STATUS (yellow) GENERAL ···1, UNIT ···1, NETWORK ···1, EMG MIC ···1, FUSE ···1, POWER ···1, CPU ···1, ZONE ···8 AMPLIFIER PEAK (red) ···4, SIGNAL (green) ···4, OPERATE (green) ···4, POWER (green) ···4 Fault Control Switch ···2 (ACK/RESET) Test Switch ···1 (LAMP TEST)
Standby Amplifier Input/Output Power Amplifier Indicators Operation	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault,
Standby Amplifier Input/Output Power Amplifier Indicators Operation Operating Temperature	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault,
Standby Amplifier Input/Output Power Amplifier Indicators	Ambient noise measuring frequency setting: 20 Hz - 20 kHz, 3 points 4 channels (with A/B LINE speaker output), 1 Earth terminal Maximum Voltage/Current: 100 Vrms, 5 Arms Connector: Removable terminal block (17 pins) ···1 Fault Detection System: Short circuit, Open circuit, Ground fault,



VOICE EVACUATION FRAME 4AB

VX-3004F

■ SPECIFICATIONS

Dimensions	483 (W) × 132.6 (H) × 345 (D) mm (19.02" × 5.22" × 13.58")
Weight	7.6 kg (16.75 lb)
Accessory	Rack mounting bracket (preinstalled on the unit) ···2, Rack mounting screw ···4, Removable terminal plug (2 pins) ···2, Removable terminal plug (4 pins) ···1,
	Removable terminal plug (6 pins) ···2, Removable terminal plug (12 pins) ···2, Removable terminal plug (17 pins) ···1, CD (PC setting software) ···1, Ferrite clamp ···2

(*1) TOA's unique technology which makes it possible to transmit high—quality audio signals in real time over an IP network. (*2) 0 dB = 1 V

